EXITS AND EMERGENCY EQUIPMENT

FIRE EXTINGUISHER OPERATION



EMERGENCY LOCATOR TRANSMITTER OPERATION

Ensure the ELT is switched to the ON position





If departing the accident site, unstrap the ELT, remove the aircraft aerial, and take the ELT with you

Attach the supplementary telescopic ELT aerial and extend





Please do not remove this card from the aircraft

Please alert your flight crew if you have any safety concerns. If you have further concerns, contact the Civil Aviation Authority on 0508 4 SAFETY (0508 472 338)